RemoteTask™

Remote Control System

"Running the RemoteTask system on a Cat® skid steer loader provides accuracy, smoothness, and an intuitive feel. Just like operating the machine from within the cab. I am very impressed!"

- Christian Nicholson, Caterpillar Design Engineer

RemoteTask allows the operator to precisely control the machine from a **safe distance**. It has been exclusively designed for all of the Cat D Series including SSL, MTL and CTL.

- •Port Handling
- •Demolition
- •Trenching
- •Landscaping
- •Steel mills
- •Mining
- •Chemical handling
- •Military/law enforcement
- •And more

1-800-530-9285 sales@torc.ai www.torc.ai

TORC®

TORC REMOTETASK™ Provides:

Ease of Use
Intuitive controller interface replicates in-cab controls, for easy operator transition.

Complete Control
The controller is integrated with:
- All work tool hydraulic controls
- Engine RPM controls
- Creeper and 2-speed

Simple, Versatile Installation
- Installs on machine in ~1 hour
- Completely transferrable between units

Remote Enable Interface
The Remote Enable Interface is affixed to the rear exterior of the machine. It contains the key switch used to enter/exit remote control and pairing modes. It also contains the Service and Ready LED indicators and an Emergency Stop Button.

Safety Features
- Two external machine indicator beacons
- Vibration motor and audible buzzer warning signals
- Remote control indicator lights for all machine warning lights, alarms and faults
- Fail safe wireless communications
- Emergency stop buttons on remote and machine

System Specifications	
Max. Operating Range	1000 ft. (Line of Sight)
Control Battery Life	24+ Hours
Frequency Band	2.4 - 2.48GHz

Office: 540.443.9262 sales@torcrobotics.com www.torcrobotics.com
TORC Robotics, Inc., All Rights Reserved.